

Chery Arrizo 5 Periodic Maintenance Schedule

عدد الشهور أو الكيلومترات ايهما أقرب													بنود الصيانة	
60000 km	55000 km	50000 km	45000 km	40000 km	35000 km	30000 km	25000 km	20000 km	15000 km	10000 km	5000 km	1000 km	KM	المحرك
R	R	R	R	R	R	R	R	R	R	R	R	R		تغيير زيت + فلتر زيت
I	I	I	I	I	I	I	I	I	I	I	I	I		فحص وجود تسريب بالمحرك (مياة تبريد، وقود، زيت)
I	I	I	I	I	I	I	I	I	I	I	I	I		فحص حالة المحرك علي السلانسيه و فحص بجهاز تشخيص الأعطال
R	I	I	I	R	I	I	I	R	I	I	I	I		فلتر الهواء
				R										تغيير فلتر الوقود
I				R				I						بوجيهات
I	I	I	I	I	I	I	I	I	I	I	I	I		فحص منظومة التبريد (ريدياتير، خراطيم، وصلات)
														تغيير سائل التبريد
I	I	I	I	R	I	I	I	I	I	I	I	I		فحص وشد سير المجموعة
				I				I						فحص منظومة الوقود (تأناك الوقود، خراطيم، وصلات)
I	I	I	I	I	I	I	I	I	I	I	I	I		فحص منظومة العادم و العزل الحراري
														منظومة الدفع
I	I	I	I	I	I	I	I	I	I	I	I	I		فحص الفيتيس (تسريب - أضرار)
														تغيير زيت فتييس
														منظومة الفرامل
I	I	I	I	I	I	I	I	I	I	I	I	I		فحص التيل و الطنابير
I	I	I	I	I	I	I	I	I	I	I	I	I		رجلاش فرامل اليد
I	I	I	I	I	I	I	I	I	I	I	I	I		فحص خطوط و مواسير و وصلات الفرامل
														زيت الفرامل
														فحص كل صيانه و تغيير بعد مرور 40 الف كيلومتر او 24 شهر
														التكليف
R	I	I	I	I	I	R	I	I	I	I	I	I		فلتر التكليف
														منظومات الكهرباء
I	I	I	I	I	I	I	I	I	I	I	I	I		فحص البطارية
I	I	I	I	I	I	I	I	I	I	I	I	I		فحص جميع الأنوار و عمل فتحة السقف (في حالة وجود فتحة سقف)
I	I	I	I	I	I	I	I	I	I	I	I	I		فحص عمل الكلاكس
I	I	I	I	I	I	I	I	I	I	I	I	I		فحص ريش المساحات و مستوى سائل المساحات
I	I	I	I	I	I	I	I	I	I	I	I	I		فحص جميع العدادات و حالة حزام الأمان
														الشاسيه
														فحص مستوى زيت الباور (في حالة الباور زيت) و مراجعة بوش علبه الدركسيون
L	L	L	L	L	L	L	L	L	L	L	L	L		تشحيم مفصلات و اقفال الكبوت والابواب
I	I	I	I	I	I	I	I	I	I	I	I	I		فحص حالة كاوتش الكوبلن
I	I	I	I	I	I	I	I	I	I	I	I	I		فحص حالة الإطارات و ضبط ضغط الإطارات
تبديل		تبديل		تبديل		تبديل		تبديل		تبديل				تبديل الإطارات
I	I	I	I	I	I	I	I	I	I	I	I	I		فحص وربط منظومة التعليق

www.chery-eg.com

f y t cheryegypt

تشحيم: L - تغيير: R - فحص: I / فترة الضمان 5 سنين أو 100,000 كم



16661






Auto

Chery Arrizo 5 Periodic Maintenance Schedule

Service Items	Number of Months or Kilometers whichever comes first													
	KM	1000 km	5000 km	10000 km	15000 km	20000 km	25000 km	30000 km	35000 km	40000 km	45000 km	50000 km	55000 km	60000 km
Engine														
Oil & Filter Change		R	R	R	R	R	R	R	R	R	R	R	R	R
Inspect engine for leakage (coolant, fuel, oil)		I	I	I	I	I	I	I	I	I	I	I	I	I
Inspect Engine Idling & operation (with diagnostic tool)		I	I	I	I	I	I	I	I	I	I	I	I	I
Air Filter		I	I	I	I	R	I	I	I	R	I	I	I	R
Fuel Filter Replace										R				
Spark plugs						I				R				I
Inspect Cooling System (Radiator,Hoses,Connction)		I	I	I	I	I	I	I	I	I	I	I	I	I
Replace Engine Coolant		I	Replace every 40,000 km or 24 months											
Inspect Drive Belt state and tension		I	I	I	I	I	I	I	I	R	I	I	I	I
Inspect Fuel System (Tank,Pipes,Connections)		I		I		I		I		I		I		I
Inspect Exhaust system and heat shields		I	I	I	I	I	I	I	I	I	I	I	I	I
Power Train														
Transaxle: check for leakage or damage		I	I	I	I	I	I	I	I	I	I	I	I	I
Change automatic transmission Fluid		I	Change first at 40,000 km, then dosen't change											
Brake System														
Inspect Disc Brakes		I	I	I	I	I	I	I	I	I	I	I	I	I
Parking brake: check the stroke		I	I	I	I	I	I	I	I	I	I	I	I	I
Inspect Brake booster, lines, hoses and connection		I	I	I	I	I	I	I	I	I	I	I	I	I
Brake Fluid		I	Inspect every maintenance and change after 40,000 km or 24 months											
Air Condition														
A/C Filter		I	I	I	I	I	I	R	I	I	I	I	I	R
Electric System														
Inspect Battery		I	I	I	I	I	I	I	I	I	I	I	I	I
Inspect All Lights Operation and sunroof (If equipped)		I	I	I	I	I	I	I	I	I	I	I	I	I
Inspect Horn Operation		I	I	I	I	I	I	I	I	I	I	I	I	I
Inspect Wiper Blades Operation& Fluid		I	I	I	I	I	I	I	I	I	I	I	I	I
Inspect All Gauges and seat belt conditidn		I	I	I	I	I	I	I	I	I	I	I	I	I
Chassis														
Power steering fluid level (If equipped) & steering gear clearance		I	Inspect power oil (in case of power oil) every maintenance, and change after 30,000 km or 24 months											
lubricate hood & doors hinges and lock catch		L	L	L	L	L	L	L	L	L	L	L	L	L
Inspect (CV) universal joint boot damage		I	I	I	I	I	I	I	I	I	I	I	I	I
Inspect Tires Condition, Pressure & Adjust		I	I	I	I	I	I	I	I	I	I	I	I	I
Tire Rotation				Rotate		Rotate		Rotate		Rotate		Rotate		Rotate
Inspect and tighten Suspension		I	I	I	I	I	I	I	I	I	I	I	I	I

www.chery-eg.com

   cheryegypt

Lubrication: L - Change: R - Check: I / Warranty period: 5 years or 100,000 km

